For age 14+

Denver DRO-170

WWW.DENVER-ELECTRONICS.COM
www.facebook.com/denverelectronics

Please read this instruction manual carefully before using the product

ENGLISH

Python

1 Instructions

Please read the user manual/book carefully and then keep it in a safe place for future consultation and maintenance.

1.1 Important Notice

(1.) This product is not a toy, it's a piece of complicated equipment which integrated with professional knowledge by mechanic, electric, air mechanic, high-frequency transmitter and so on, so it should be installed correctly and adjusted to avoid any accidents.

The owner must anyhow operate it in a safe manner, if improper operation that caused human injured or property damage, then we DENVER ELECTRONICS A/S accept no liability for any safety duties from operation. As we have no control over the way they operate and use the product.

(2.) This product is not suitable for users under 14 years of age.

(3.) The use of the drone may not prohibited in some areas like bare stations, airports, aircrafts, crowded areas etc. You should check with the authorities whether the use of the drone is permitted in some public or private areas. Always use the drone bearing in mind not to breach people's privacy. We exclude liability for any losing one of the drone.

(4.) We DENVER accept no liability for any safety duties or lines arising from operation, usage or misuse/out after the sale of products. (Namely does not cover if drone crashes and get damaged

1.2 Safety Precautions

Keep away from crowd when flying, since drone flight is a high risk hobby. Misoperation or broken outer blades or defective electronics equipment or unskilled operation may cause accidents of machine damaged or injured. Please pay special attention to safety operation.

(1.) Keep away from sundry and obstacles.

"The flying speed and status of the drone is uncertain, so it may cause potential danger."

When choosing a flying site should stay away of buildings, trees and power lines. AVOID flying in or near crowded areas. Meanwhile avoid flying in rain, storms, thunder and lightening to protect electronics and parts out of damage.

(2.)Keep away from hazard environment.

Inside of drone is made up of precise electronic components. Stay away from humidity or water vapor to protect machinery and parts.

(3.) Safety operation

Please fly your drone according to your physical status and flight skill. Fatigue, drowsiness and mis-operation will increase possibilities of accidents/ hazard.

(4.) Keep away from rotating blades

Keep your face and body as well as all operations away from the rotating blades. The spinning blades of a model of the type can cause serious injury.

(5.) Re-movement flying the drone below 10 meters of height.

(6.) Keep away from mud

Autonics made up of metal, fiber, plastic, electronic components, etc. Keep it away from mud and sundries to avoid distortion, and damage.

1.3 Crash Lot Before Free Flight

(1.) Flying field should be in an open space and no luggage at least 5M length *5M wide *3M height

(2.)Make sure the receiver and transmitter is fully charged.

(3.)Paddle directly obey the order of turn on, turn off button operation. When starting your flight, first turn on the transmitter, and connect the battery with drone last. When finishing your flight, please disconnect the battery from your drone first, turn off transmitter last. An upset in the order of connection may cause your drone loose control to threaten yourself and others safety. Please follow such set table of turn on and turn off.

(4.)Make sure the connection is solid between battery or motor. The ongoing vibration may cause bad connection of power terminal and make the drone unsportstable.

Battery Installation & Charging

Wrist Controller

The 3 pcs battery is built inside the wrist controller. Before use, please fully charge it with the USB charging cable from the package.

Note

- When the remote controller is not paired with the drone in 1 minute, it will power off automatically.
- When the remote controls enters into the low-voltage status, the indicator lights flash slowly and it needs to be charged.

Charging

Connect one side of the USB connector with the battery, and the other side into any USB port of computer or a smartphone charger (not included).

Drone

Replacing the damaged blades:

Your set will come with 4 spare rotors, two type A (ccw) and two type B (cw) etc. You will see the "A" and "B" mark on the canopy, then put the rotor on the motor accordingly.

Wrist Controller (Gravity Sensor)

1. Power button

Power On: short press.

Power Off: long press for 5 seconds.

Gyro Reset: short press (before the drone takes off).

Landing: short press.

Emergency Stop: long press for 2 seconds.

2. Finger motors

Take-off: short press.

Flip/Roll: short press, then tilt/tilt the wrist.

Ascend: long press and tilt the wrist forward.

Descend: long press and tilt the wrist backward.

Left Rotation: long press and tilt the wrist to the left.

Right Rotation: long press and tilt the wrist to the right.

IR induction mode: short press for 3 times quickly to enter/exit the IR induction control.

Quick Start-up Steps

1. Turn on the drone
Put the drone on the ground and press the power button. The LED on the drone flash twice.

2. Turn on the wrist controller
When the LED on the controller is on, the drone will automatically connect with the controller. The LED on the drone will stay on when connected.

3. Load Tasks off
When the drone connects with the controller, the LED on the drone will stay on. Now you can load tasks and control the drone.

Gyro Reset

Before first flying or the drone crashes to the ground, Gyro Reset is necessary to fix drone to make sure the drone will take off correctly and fly stably.

Short press the power button on the wrist controller. LEDs on the drone will flash very quickly, then remain ON.

Then, the Gyro Reset complete.

Main Functions

1. Forward / Backward / Leftward / Rightward

a. Forward: Tilt the wrist forward.

b. Backward: Tilt the wrist backward.

c. Leftward: Tilt the wrist to the left.

d. Rightward: Tilt the wrist to the right.

2. Ascend / Descend / Left Rotation / Right Rotation

a. Ascend: Long press the finger button, and fold the wrist forward.

b. Descend: Long press the finger button, and fold the wrist backward.

c. Left Rotation: Long press the finger button, and tilt the wrist to the left.

d. Right Rotation: Long press the finger button, and tilt the wrist to the right.

3. Flip / Roll

a. Flip forward: Short press the finger button, then fold the wrist forward quickly.

b. Flip backward: Short press the finger button, then fold the wrist backward quickly.

c. Flip Leftward: Short press the finger button, then tilt the wrist to the left quickly.

d. Flip Rightward: Short press the finger button, then tilt the wrist to the right quickly.

4. Landing / Emergency Stop

a. Landing: During flight, short press the power button, the drone lands slowly.

b. Emergency Stop: During flight, long press the power button for 1 second, the drone falls down directly to the ground.

5. Infrared (IR) Induction mode

During flight, short press the finger button for 3 times quickly, the LED is on the drone flash 3 times quickly and the drone will enter the IR induction mode.

The drone detects the non-transparent obstacles, like: walls and user's hands.

Once obstacles are detected, the drone will back to inside, the opposite direction.

Note

- After IR induction mode is ON, the wrist control mode is still available.
- Short press the finger button again for 3 times quickly, the IR induction mode is OFF.
- If the wrist controller is powered OFF with the IR induction mode still ON, the drone will be always ready for IR induction's mode—when it's powered on next time and it will support this mode by.

Main Accessories

1 mm Battery | Blades | USB Charge cable | Wrist controller

Please notice - All products are subject to change without any notice.
We take reservations for errors and omissions in the manual.
ALL RIGHTS RESERVED. COPYRIGHT DENVER ELECTRONICS A/S

DENVER
denver-electronics.com

Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) are not handled correctly.

Electric and electronic equipment and batteries are marked with the crossed out trash bin symbol, as below. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end-user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Inter Sales A/S declares that the radio equipment type DENVER DRO-170 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: Please enter: www.denver-electronics.com and then click the search ICON (or typein of website. Write model number. Ex: 170. Now enter product page and KLIK/Marker on found under downloads/Other downloads).

Operating Frequency Range: 2408 MHz - 2472 MHz
Max Output Power: 7 mW

DENVER ELECTRONICS A/S
Omega 4A, Stadion
DK-5000 Odense
Denmark
www.facebook.com/denverelectronics