





Parts List



A x 1



B x 2



C x 4



Black
D x 4




Black
E x 4




Silver
F x 4




G x 4



H x 1




I x 1



J x 1



K x 2




L x 1


Intel Installation Guide

1

① LGA1200/1156/1155/
1151/1150
② LGA1700



① LGA1200/1156/1155/
1151/1150
② LGA1700



2




LGA1700

or


LGA1200/115X

or


LGA2600/2011




3




4




5



6



AMD Installation Guide



Fan & MB SYNC Installation Guide

⚠ CAUTION

Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. Connecting the wrong end can damage the fans.

